



Wireless Control Box



CB-001



CB-002



Functions Description

ON/OFF	Turn on/ off the warning lightbar;	BY DAY/ BY NIGHT	Switch to By Day or By night (warning lightbar);	LEFT ALLEY	Turn on/ off Left Alley;
RIGHT ALLEY	Turn on/ off Right Alley;	NEXT	Switch to the next flashing pattern;	BACK	Switch to the former flashing pattern;
CRUISE	Turn on/ off Cruise;	TAKE DOWN	Turn on/ off Take Down;	RESET	Switch to the first (default) flashing pattern.

Display On The Control Box

"b"	To show the lightbar is not connecting with the control box;
"0" - "9"	To show the Battery Fuel Gauge of control box; "0" : 0%~9% , "9" : 90%~99% ;
"P"	When the control box receives the pairing signal from lightbar, the control box will display a "P" to show it's pairing;
"d"	When the control box receives the confirmation signal from lightbar, the control box will display a "d" to show pairing is done;
"C"	When charging, a "C" will be displayed; (AAA battery Re-chargable version)
"F"	When finished charging, an "F" will be displayed; (AAA battery Re-chargable version)
"U"	When supplied by USB, a "U" will be displayed

Part NO.	Function	Voltage	Material	Connection	Temperature
CB-001	Wireless control box for warning lightbar	DC 5V	ABS	Micro USB	-20°C to +50°C
CB-002	Wireless control box for warning lightbar with take down and alley function			AAA Battery(Rechargeable) AAA Battery(non-rechargeable)	